

ПЕРЕД ПЕРВЫМ ВКЛЮЧЕНИЕМ

Встраиваемый телевизор для кухни AVEL, модель AVS220W / AVS220K / AVS240K

- Проверьте подключение к сети электропитания. Для проверки убедитесь, что горит светодиодный индикатор на блоке питания, и на передней панели телевизора.
- В комплекте поставляется два пульта, **один из которых защищён от брызг и струй воды, но не от погружения (степень защиты IP66)**. Влагозащищённый пульт оснащён элементом питания стандарта **CR2032**. В некоторых случаях, оба пульта могут не комплектоваться батарейками в связи с требованием безопасности при авиатранспортировке.
- Для запуска видео или фото файлов с USB носителя, используйте кнопку Enter (выбранный файл будет воспроизводиться в окне предварительного просмотра) и кнопку Play для начала воспроизведения во весь экран.

PRIOR TO FIRST USE / FAQ

AVEL Cabinet Door TV for Kitchen, model AVS220W / AVS220K / AVS240K

- Check mains power connection. Make sure that LED, on the power supply adapter and on the TV front panel, is ON.
- There are 2 remote controls included in the standard package. **One remote is waterproof, and it has IP66 protection ranking (protection against water jets — don't immerse in water!).** Waterproof remote control works with **CR2032** battery type. Batteries for remote controls may be absent due to air transportation restrictions.
- To start video or photo files from a USB memory stick or HDD, please use “Enter” button to highlight files and then “Play” button to start playback in full screen mode.